



How to setup ActiveX for DVR,NVR,IP camera.

1. Start by clicking on tools (gear in the image) and going to Internet options




-Next page-

2. Go to the Security tab and click on the Custom level button.



-Next page-

3. Locate the ActiveX control settings and make sure that they are all enabled. If the enable option says (not secure) set that option to prompt. Then hit ok.



-Next page-

4. Next click on the green check mark that says Trusted sites. Next click on the Sites button. Add your dvr's IP to your list of trusted sites. (when adding your ip make sure that the "Require server verification" check box at the bottom is unchecked. After adding you ip click close.

5. Next click on the Custom level button and locate the Activex control settings and make sure that they are all enabled. If the enable option says (not secure) set that option to prompt. Then hit ok. You activex controls are now all enabled and you will be able to view your DVR online.

-Images for steps 4 and 5 are on the following pages-

Internet Options - Security At Risk


General Security Privacy Content Connections Programs Advanced

Your security settings put your computer at risk

Select a zone to view or change security settings.


Internet Local intranet **Trusted sites** Restricted sites

Trusted sites

 This zone contains websites that you trust not to damage your computer or your files.
You have websites in this zone.

Sites

Trusted sites

 You can add and remove websites from this zone. All websites in this zone will use the zone's security settings.

Add this website to the zone:

Add

Websites:

Remove

Require server verification (https:) for all sites in this zone

Close

